

Service Technical Information

I. Communication Subject

Communication No.: TW-ALL-DS-2025042401

Release date: April 24th,2025

Communication name: IM All-round Diagnostic(ADS) User Manual

Communication type: Technical World

Related vehicle models: ALL

Related vehicles: ALL

II. Communication Content

Preface

IM All-round Diagnostic System(ADS), which is an online diagnostic system used for vehicles with a brand-new electrical architecture

The content of this user manual is based on ADS version1.0.35. Its functions and operations are introduced and explained in two chapters, aiming to help maintenance engineers correctly and fully understand and use the diagnostic tool in their daily work, and improve work efficiency. With the update of the ADS version, a new version of the user manual may be released. At that time, this user manual will automatically become invalid. Please pay attention to the release of the new version of the user manual

Chapter I Introduce the functional composition, operating environment and system interface of ADS

Chapter II Introduce all the functions of the ADS client and the corresponding operation instructions

This communication adds ADS offline package management function and authorization process introduction on the basis of the original. Effective immediately, the original *TW-ALL-DS-2025022801-IM All-round Diagnostic (ADS) User Manual* is invalid. Please pay attention to it.

Version Information

| Version | Date | Revisor | Revision Record |
|---------|-----------|-------------|---|
| V1.0 | 2025-2-28 | FU Xinliang | 1. Compile the first edition of the ADS User Manual |
| V1.1 | 2025-4-24 | FU Xinliang | 1. Add the function introduction of Package Management 2. Add ADS authorization process introduction 3. Optimize some function descriptions |
| | | | |
| | | | |

Contents

| | |
|---|-----------|
| PREFACE | 1 |
| VERSION INFORMATION | 2 |
| CONTENTS | 3 |
| CHAPTER I INTRODUCTION TO IM ALL-ROUND DIAGNOSTIC SYSTEM (ADS) | 5 |
| 1.1. INTRODUCTION TO THE ADS CLIENT | 5 |
| 1.1.1. Introduction to the Operating Environment of ADS | 5 |
| 1.1.2. Installation Process of ADS Software | 6 |
| 1.1.2.1. Software Download | 6 |
| 1.1.2.2. Software Installation | 6 |
| 1.1.3. Login to the ADS Client | 8 |
| CHAPTER II INTRODUCTION TO THE FUNCTIONS OF ADS | 10 |
| 2.1. VEHICLE IDENTIFICATION | 10 |
| 2.1.1. The steps of "Vehicle Identification" | 11 |
| 2.2. BASIC INFORMATION | 12 |
| 2.2.1. Vehicle Information | 12 |
| 2.2.2. ECU Information | 14 |
| 2.2.2.1. Introduction to the Controller List Information | 15 |
| 2.2.2.2. Introduction to the Matching Status | 15 |
| 2.2.2.3. ECU Information Re-read and Export Function | 16 |
| 2.3. BASIC DIAGNOSIS | 16 |
| 2.3.1. Vehicle Scan | 16 |
| 2.3.1.1. Introduction to the interface of Vehicle Scan | 17 |
| 2.3.1.2. Controller View of Vehicle Scan | 17 |
| 2.3.1.3. Vehicle Scan | 18 |
| 2.3.1.4. ECU Basic Diagnosis Function | 19 |
| 2.3.2. Data Playback | 23 |
| 2.4. ECU FUNCTION | 24 |
| 2.4.1. ECU replacement | 24 |
| 2.4.1.1. Introduction to the display of ECU Replacement | 24 |
| 2.4.1.2. Operation Process of ECU Replacement | 26 |
| 2.5. ROUTINE | 33 |
| 2.5.1. Introduction to the interface of Routine | 33 |
| 2.5.2. Routine - Operation Steps for Add NFC | 34 |
| 2.6. BASELINE MANAGEMENT | 39 |
| 2.6.1. Baseline Serial | 39 |

| | |
|--|-----------|
| 2.6.1.1. Introduction to the Controller List | 40 |
| 2.6.1.2. Introduction to Function List | 43 |
| 2.6.1.3. Introduction to the Operation Steps of Baseline Serial | 43 |
| 2.7. PACKAGE MANAGEMENT | 46 |
| 2.7.1. Offline Package | 46 |
| 2.8. AUXILIARY FUNCTIONS | 46 |
| 2.8.1. Home Page | 47 |
| 2.8.2. Open the File Synchronization Tool | 47 |
| 2.8.3. Open VCI Manager | 48 |
| 2.8.4. Help Documentation | 48 |
| 2.8.5. Setting | 49 |
| 2.8.6. Export Logs | 49 |
| 2.8.7. Online/Offline Mode Switching | 50 |
| 2.8.8. Connect Status | 50 |
| CHAPTER III OTHER MATTERS | 51 |
| 3.1. ENVIRONMENTAL SETTINGS | 51 |
| 3.1.1. Steps for Firewall Settings | 51 |
| 3.1.2. MSMQ (Microsoft Message Queue) Settings | 54 |
| 3.1.3. Route Settings | 55 |
| 3.1.4. Computer's IP Address Setting | 57 |
| 3.2. FREQUENTLY ASKED QUESTIONS | 60 |
| 3.2.1. The vehicle cannot be identified and prompts "DoIP network connection failed" | 60 |
| 3.3. ANY QUESTION, PLEASE CONTACT THE TAC OF THE CORRESPONDING REGION | 60 |

Chapter I Introduction to IM All-round Diagnostic System(ADS)

The IM All-round Diagnostic System (ADS) realizes the maintenance and upkeep of vehicles through online diagnosis. It provides functions such as vehicle diagnostic functions (including reading fault codes, real-time display, action test, module information, etc.), baseline management, ECU replacement, and routine (functions like add/delete NFC, calibration of intelligent driving cameras, etc.).

The ADS system is composed of three parts: the ADS client, configuration information query, and module information query

- ADS client:Communicate with the vehicle through an OBD (On-Board Diagnostics) network cable to achieve vehicle maintenance and repair functions
- Configuration Information Query:Query the configuration information of the vehicle
- Module information query:Query the latest software information of the vehicle in the database

1.1. Introduction to the ADS Client

After the ADS client is installed on the local computer, connect to the vehicle via an OBD network cable to achieve the maintenance and repair of the vehicle.

1.1.1. Introduction to the Operating Environment of ADS

To ensure the normal operation of ADS, the following basic conditions need to be met:

- ✓ The computer's hardware and software should meet the standardized configuration requirements of the after-sales diagnostic system



Note

For specific requirements, please refer to *TB-EP33L-GE-2025040102-Standardization of After-sales Diagnostic System*


- ✓ The current user needs to have Windows administrator privileges
- ✓ Confirm that the Windows Defender Firewall of the diagnostic computer has been completely turned off
- ✓ Confirm that no antivirus software,PC management software,or similar software is installed on the diagnostic computer
- ✓ During the use of the ADS client, connect the diagnostic computer and the vehicle with an OBD network cable
- ✓ During the use of the ADS client,it is necessary to obtain information from the database,please ensure that the network connection is normal when it is running



1.1.2. Installation Process of ADS Software


1.1.2.1. Software Download

- a. Log in TIS system
- b. Functional path: Technical Information → TI Viewing. Search by the keyword "ADS Release", download the installation package of the ADS software according to the requirements of the technical information, and refer to ***TW-ALL-OS-2024041701-TIS User Manual***




1.1.2.2. Software Installation


- a. Double-click the ADS client installation package
- b. Select the installation language (Chinese is the default), and click the [OK] button



c. Click the [Next] button



d. Click the [Finish] button




e. Automatically generate a shortcut on the desktop




1.1.3. Login to the ADS Client

(1) Software Startup

- Double-click the ADS shortcut to launch the ADS client
- On the login interface, enter your personal account and password, and click the [Login] button




- Pop up a dialog box, prompting that the ADS is not authorized. Click the [Submit] button, and then log in again to use it




Note

- There are two scenarios that require authorization: a. Install ADS for the first time on a new computer, b. Log in after the authorization expires
- Authorization approval takes some time. Please wait for 3-5 minutes after submitting the application and log in to ADS again

d. After logging in, a dialog box will pop up, prompting whether to open the file synchronization tool. Click the "Yes" or "No" button as needed



e. The interface displays the ADS homepage, that is the vehicle identification page




Chapter II Introduction to the Functions of ADS

After the vehicle identification is completed, the system will automatically enter the function interface of ADS. This interface contains six major functional blocks, corresponding to eight functions. The details are shown in the following table.

| Basic Information | Basic Diagnosis | ECU Function |
|---------------------|-----------------|-----------------|
| Vehicle Information | Vehicle Scan | ECU Replacement |
| ECU Information | Data Playback | -- |

| Routine | Baseline Management | Package Management |
|---------|---------------------|--------------------|
| Routine | Baseline Serial | Offline Package |

The main functions of ADS are shown in the left menu bar of the figure below, which can be switched by clicking. The content of this manual is based on the ADS V1.0.35, and the version number can be viewed in the lower right corner of the ADS interface



2.1. Vehicle Identification

After the ADS client is opened, the main interface for vehicle identification is displayed by default. Click the [Vehicle Identification] button to start establishing communication with the vehicle and complete the operation of vehicle identification. When identifying the vehicle, after the ADS obtains relevant data according to the identified VIN, it will automatically jump to the "Vehicle Information" tab and update the relevant information in the status bar.

When identifying the vehicle, the ADS reads the vehicle's VIN from the vehicle's key modules (the key modules generally include the ICC/ICB,BCM,and SDM.The definitions of key modules may vary among different vehicle models).



Caution

- After the identification is completed, make sure that the VIN is correct to avoid irreversible consequences such as software or configuration errors, and even damage to the modules.
- During the vehicle maintenance process, you can click to return  to the vehicle identification homepage

2.1.1. The steps of "Vehicle Identification"

Step1:Connect the vehicle and the diagnostic computer running ADS with an OBD network cable

Step2:Keep the vehicle powered on and ensure that the driver's side screen is lit up



Step3:Start the ADS client and click the [Vehicle Identification] button on the main interface

Step4:Read the VIN information of the key vehicle modules and display the reading results. The VIN reading results are divided into the following situations:

- ✓ If it is completely consistent (except that all key modules are new parts), the read VIN will be used as the VIN for vehicle identification for all subsequent operations.
- ✓ If it is not completely consistent, a pop-up window will prompt the user to manually enter the VIN(with two verification steps to ensure consistency).Moreover,the entered VIN must be within the range of the VINs read from the key modules. In this case, the manually entered VIN will be used as the VIN for vehicle identification for all subsequent operations
- ✓ When the normal VIN cannot be read for all key modules, a pop-up window is used to prompt the user to manually enter the VIN (with two validations to ensure consistency)

Step5:The VIN finally determined according to the judgment logic shall be used as the VIN for vehicle identification. Use this VIN to read the relevant information of the vehicle, and obtain the relevant information in the database through the network

Step6:After the vehicle identification is completed, enter the ADS function interface, which defaults to the vehicle information interface

2.2. Basic Information

Basic Information function includes Vehicle Information function and ECU Information function

2.2.1. Vehicle Information

Vehicle Information function: Display the vehicle configuration, include VIN, Odometer, Platform, Mode, Feature code list and detailed configuration list

Introduction to the Information Displayed on the Interface

| Information | Description |
|---|--|
| VIN | The VIN (Vehicle Identification Number) of vehicle identification |
| Odometer value | The mileage of the vehicle |
| Platform | The platform information corresponding to the VIN of vehicle identification |
| Model | The model information corresponding to the VIN of vehicle identification |
| Feature code list | The configuration list corresponding to the VIN of vehicle identification |
| Local Vehicle Global OS Version | The vehicle global OS version of the current vehicle |
| Server Vehicle Global OS Version | The latest vehicle OS version in server of the current vehicle |
| Local Vehicle Global Part Number Version | The vehicle software number of the current vehicle |
| Server Vehicle Global Part Number Version | The latest software number in server of the current vehicle |
| Detailed Configuration List | The feature code list and their corresponding descriptive information of the VIN of vehicle identification |
| Feature Code | The feature code list of the current vehicle |
| Feature Code Description | Each feature code descriptive information of the current vehicle |

2.2.2. ECU Information

ECU Information function: Taking the controller as a unit, display the software and hardware information read from the vehicle controller and the latest software and hardware data information queried from the database, and show the matching status



Note

- The VIN code information in the database of each controller is actually the VIN code of vehicle identification
- The list of controllers displayed in this table only shows all the controllers that the current vehicle supports for diagnosis

| ADS Online Mode | | | | | | | |
|---|---|------------------------------|-------------------|--|----------------------|-----------------|-------------|
| ECU Information | | | | | | | |
| VIN: LSJWR4092RS083954 Vehicle Description: 国家或地区代码/S12/品牌名称/车型系列/车型年/--- Authorization Days: 363 | | | | | | | |
| | | SW | Project | Vehicle ECU Information(Click Show V...) | Database Information | Matching Status | Description |
| Basic Information | | | | | | | |
| AMP (Audio System Power Amplifier) | | | | | | | |
| Vehicle Information | 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | | ✓ | |
| | 2 | Base Model Part Number | 11909324 | 11909324 | | ✓ | |
| | 3 | Operating Software | 11874048 | 11874048 | | ✓ | |
| | 4 | Configuration File | 11649569 | 11649569 | | ✓ | |
| Basic Diagnosis | | | | | | | |
| BCM (Body Control Module) | | | | | | | |
| Vehicle Scan | 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | | ✓ | |
| | 2 | Base Model Part Number | 11765325 | 11765325 | | ✓ | |
| | 3 | Operating Software | 11889763 | 11949441 | | ✗ | |
| | 4 | Calibration File 2 | 11865355 | 11951611 | | ✗ | |
| Data Playback | 5 | Calibration File 3 | 11830172 | 11830172 | | ✓ | |
| | 6 | Configuration File | 11889765 | 11849447 | | ✗ | |
| ECU Function | | | | | | | |
| BMS (Battery Management System) | | | | | | | |
| Routine | 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | | ✓ | |
| | 2 | Base Model Part Number | 11462183 | 11462183 | | ✓ | |
| | 3 | Operating Software | 11894785 | 11894785 | | ✓ | |
| | 4 | Configuration File | 11866976 | 11866976 | | ✓ | |
| Package Management | | | | | | | |
| BPEPS (Bluetooth Passive Entry Passive Start) | | | | | | | |
| | 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | | ✓ | |
| | 2 | Base Model Part Number | 11365384 | 11365384 | | ✓ | |
| | 3 | Operating Software | 11748037 | 11950228 | | ✗ | |
| | 4 | Calibration File 1 | 11846899 | 11950229 | | ✗ | |
| | 5 | Configuration File | 11782252 | 11782252 | | ✓ | |
| CCU (Combined Charger Unit) | | | | | | | |
| | 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | | ✓ | |

2.2.2.1. Introduction to the Controller List Information

Project: The controller information data entries supported by each controller. The entry data varies depending on the different controllers


Vehicle ECU Information: The controller information read from the vehicle

Small Version: Click Vehicle ECU Information will display or hide the small version

Database Information: The latest controller information obtained from the database according to the vehicle identification VIN. This data information can be written into the controller through the "diagnostic function"

Matching Status: The comparison results between the "Vehicle ECU Information" and the "Database Information" for each piece of data, include , 

Description: The explanatory information corresponding to the "database information" of each piece of data



| ECU Information | SN | Project | Vehicle ECU Information(Click Show V...) | Database Information | Matching Status | Description |
|--|------------------------------|-------------------|--|----------------------|-----------------|-------------|
| AMP (Audio System Power Amplifier) | | | | | | |
| 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | LSJWR4092RS083954 | ✓ | |
| 2 | Base Model Part Number | 11909324 | 11909324 | 11909324 | ✓ | |
| 3 | Operating Software | 11874048 | 11874048 | 11874048 | ✓ | |
| 4 | Configuration File | 11649569 | 11649569 | 11649569 | ✓ | |
| BCM (Body Control Module) | | | | | | |
| 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | LSJWR4092RS083954 | ✓ | |
| 2 | Base Model Part Number | 11765325 | 11765325 | 11765325 | ✓ | |
| 3 | Operating Software | 11889763 | 11889763 | 11949441 | ✗ | |
| 4 | Calibration File 2 | 11865355 | 11865355 | 11951611 | ✗ | |
| 5 | Calibration File 3 | 11830172 | 11830172 | 11830172 | ✓ | |
| 6 | Configuration File | 11889765 | 11889765 | 11949447 | ✗ | |
| BMS (Battery Management System) | | | | | | |
| 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | LSJWR4092RS083954 | ✓ | |
| 2 | Base Model Part Number | 11462183 | 11462183 | 11462183 | ✓ | |
| 3 | Operating Software | 11894785 | 11894785 | 11894785 | ✓ | |
| 4 | Configuration File | 11866976 | 11866976 | 11866976 | ✓ | |
| BPEPS (Bluetooth Passive Entry Passive Start) | | | | | | |
| 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | LSJWR4092RS083954 | ✓ | |
| 2 | Base Model Part Number | 11365384 | 11365384 | 11365384 | ✓ | |
| 3 | Operating Software | 11748037 | 11748037 | 11950228 | ✗ | |
| 4 | Calibration File 1 | 11846899 | 11846899 | 11950229 | ✗ | |
| 5 | Configuration File | 11782252 | 11782252 | 11782252 | ✓ | |
| CCU (Combined Charger Unit) | | | | | | |
| 1 | Vehicle Identification Nu... | LSJWR4092RS083954 | LSJWR4092RS083954 | LSJWR4092RS083954 | ✓ | |

2.2.2.2. Introduction to the Matching Status

: The "Vehicle ECU Information" and the "Database Information" corresponding to the data entries are consistent

: The "Vehicle ECU Information" and the "Database Information" corresponding to the data entries are inconsistent


2.2.2.3. ECU Information Re-read and Export Function

Re-Read

:Re-read the information of all the controllers of the vehicle, and compare it again with the information in the database. Update the display information on this interface. The updates include: the controller list, the data list of each controller, the vehicle ecu information and database information of each piece of data, and update the display

Export Logistics Data

:Export the currently read information of the vehicle's overall controllers and automatically save it to the default directory on the disk C




2.3. Basic Diagnosis

Basic Diagnosis includes two functions: Vehicle Scan and Data Playback

2.3.1. Vehicle Scan

Vehicle Scan: It can implement functions such as reading and clearing fault codes, reading the freeze frame of a single controller, real-time display of data streams, action tests, reading module information, exporting DTC reports and diagnostic reports



2.3.1.1. Introduction to the interface of Vehicle Scan

The interface of Vehicle Scan includes functional buttons such as Icon View, List View, Start Scan, Clear Vehicle DTC, and Export DTC Report.



Note


The results of Vehicle Scan will not be retained after re-performing the vehicle identification

2.3.1.2. Controller View of Vehicle Scan

The controller view of Vehicle Scan is divided into an icon view and a list view. The content includes data such as the controller name, status, bus type, and fault situation


2.3.1.2.1. Icon View

Icon View:



2.3.1.2.2. List View

List View:



Full Vehicle Scan VIN: LSJWR4092RS083954 Vehicle Description: 国家或地区代码/S12/品牌名称/车型系列/车型年/--- Authorization Days: 363


| No. | Vehicle Module | DTC Count | CommState |
|-----|----------------|--|-----------|
| 1 | AMP | 0 | Normal |
| 2 | BCM | 0 | Normal |
| 3 | BMS | 0 | Normal |
| 4 | BPEPS | 3 | Normal |
| | B178200 | Slave Function Abnormal-Bump | Pending |
| | B178400 | Slave Function Abnormal-Left Front Door | Pending |
| | B178500 | Slave Function Abnormal-Right Front Door | Pending |
| 5 | CCU | 0 | Normal |
| 6 | EOPC | 0 | Normal |
| 7 | EPMCU | 0 | Normal |
| 8 | EPS | 0 | Normal |
| 9 | FDR | 0 | Normal |
| 10 | FLDCM | 0 | Normal |
| 11 | FLSM | 0 | Normal |
| 12 | FRDCM | 0 | Normal |
| 13 | FRSM | 0 | Normal |
| 14 | IAM | 0 | Normal |

Click on "Start Scanning" to get the latest information Total Number Of DTCs: 15

Buttons: Prompt Information Page, Icon View, **List View**, Start Scan, Clear Vehicle DTC, Import Engineering Parameter, Export DTC Report

2.3.1.3. Vehicle Scan

Start Scan: After clicking, it will start to read the data of all vehicle modules. Once the scan is completed, a diagnostic report will be generated and saved to the following path




Vehicle Scan

Scan Complete, Report save
 path: C:\ADS\PDF\DiagnosticReport\ADSReport_LS
 JWL4091NS119001_20250222150831.pdf

OK

Clear Vehicle DTC: After clicking, it will start to clear the fault codes of the entire vehicle. After the clearing is completed, it will read back the fault codes of the entire vehicle and update the status of the controllers

Export DTC Report: After clicking, a DTC report will be generated according to the current reading result of the fault codes and saved to the following path



Export Report

The export was successful. File path :
 C:\ADS\PDF\DtcReport\ADS_DTC_Report_LSJW409
 XSS033438_20250415195941.pdf

OK



2.3.1.4. ECU Basic Diagnosis Function

1. Click ECU name



Note

- Icon View: click
- List View: double-click




2. Enter the ECU details interface. This interface includes the functions supported by the current ECU itself, such as DTC, Real-Time Display, action test, module info



Note

The ECU name is displayed on the upper left side of the details interface, as shown in the figure below




2.3.1.4.1.DTC

Read and clear fault codes and read frozen frames



Note

- In the ECU details interface, only support read and clear fault codes of the current ECU
- Select a fault code to read the freeze frame of the fault code




The screenshot shows the 'DTC' tab in the 'Basic Diagnosis' section. The 'DTC Info' table lists three fault codes:

| No. | DTC | 故障类型 | DTC description | DTC Status | 次数 | 冻结帧 | Guide |
|-----|-------|------|--|------------|----|-----|-------|
| 1 | B1782 | 00 | Slave Function Abnormal-Bump | Pending | | | |
| 2 | B1784 | 00 | Slave Function Abnormal-Left Front Door | Pending | | | |
| 3 | B1785 | 00 | Slave Function Abnormal-Right Front Door | Pending | | | |

At the bottom of the interface, a green notification bar states: "Read DTC Successfully, 3 DTC!". Below this bar are three buttons: "Read DTC", "Clear DTC", and "Read Freeze Frame".

2.3.1.4.2.Real-Time Display

1.Check the data items, click the [Start] button, and the diagnostic tool will automatically read the real-time data stream




The screenshot shows the 'Real-Time Display' tab in the 'Basic Diagnosis' section. The 'Data Item' table lists three items:

| Data Item | Value | Unit | Graphic |
|--|-------------|------|--------------------------|
| System Operational Mode | Normal Mode | | <input type="checkbox"/> |
| Current Radar Horizontal Deviation Angle | -0.19 | ° | <input type="checkbox"/> |
| Current Radar Vertical Deviation Angle | -0.70 | ° | <input type="checkbox"/> |

At the bottom of the interface, there is a 'Pause' button and a play button icon.

2.It can display the data stream values and graphs



3.It supports the recording of the data stream

-  :Start recording
-  :End the recording
-  :Start read the data stream



Note


- Before starting the recording and reading, you need to check the corresponding data items in the box on the far left of the list.
- If you need to display the graphic, you need to check the corresponding data items in the boxes of the graphic column.

4.After the recording is completed, the ADS will pop up a window prompting you to save the recorded data stream file for data playback (refer to [Chapter II Introduction to the Functions of ADS -> 2.3 Basic Diagnostic -> 2.3.2 Data Playback](#))

2.3.1.4.3.Action Test


This function is mainly used to force the ECU to perform the action of the selected item and confirm whether its function is normal

Select the item as needed, click the [Execute] button, and check the actual execution performance of the vehicle




2.3.1.4.4.Module Info

Read the module information of the selected ECU, and the module information will be displayed in the corresponding column of "Value" on the right side




2.3.2. Data Playback

For the recorded data stream file, you can import the file on the data playback page and then play it back for viewing



After importing, you can click to select the corresponding data item for playback



 :Start Playback

 :Pause Playback

 :End Playback


2.4. ECU Function

ECU Function include ECU Replacement

2.4.1. ECU replacement

Click on the "ECU Replacement" tab, and the controller list, information prompt page and other contents will be displayed

ECU Replacement Function:It is mainly used for operations such as ECU reprogramming, configuration, and calibration after replacing the ECU hardware. These operations are to flash the ECU to the state of the local baseline version and enable it to achieve the functions it should have



| SN | ECU Name | Status | Reprogramming File | Configuration File |
|----|---|--------|--------------------|--------------------|
| 1 | AMP(Audio System Power Amplifier) | Normal | ✓ | ✓ |
| 2 | BCM(Body Control Module) | Normal | ✗ | ✗ |
| 3 | BMS(Battery Management System) | Normal | ✓ | ✓ |
| 4 | BPEPS(Bluetooth Passive Entry Passive Start) | Normal | ✓ | ✓ |
| 5 | CCU(Combined Charger Unit) | Normal | ✓ | ✓ |
| 6 | EOPC(Electrical Oil Pump Controller) | Normal | ✗ | ✓ |
| 7 | EPMCU(Electrical Parking Motor Control Unit) | Normal | ✓ | ✓ |
| 8 | EPS(Electric Power Steering System) | Normal | ✓ | ✓ |
| 9 | FDR(Front Detection Radar) | Normal | ✓ | ✓ |
| 10 | FLDCM(Left Rear Door Control Module) | Normal | ✓ | ✓ |
| 11 | FLSM(Front Left Seat Module) | Normal | ✓ | ✓ |
| 12 | FRDCM(Left Rear Door Control Module) | Normal | ✓ | ✓ |
| 13 | FRSM(Front Right Seat Module) | Normal | ✓ | ✓ |
| 14 | IAM(Communication Module) | Normal | ✗ | ✓ |
| 15 | IBS(Brake Master Cylinder Booster Module) | Normal | ✓ | ✓ |
| 16 | ICB(Intelligent Computing Domain Controller Module) | Normal | ✗ | ✓ |
| 17 | IMU(Inertial Navigation Module) | Normal | ✓ | ✓ |
| 18 | IPD(Intelligent Pilot Device) | Normal | ✗ | ✓ |
| 19 | ITMS(Heating, Ventilation and Air Conditioning) | Normal | ✓ | ✓ |
| 20 | LHRDA(Left Rear Drive Assist Module) | Normal | ✓ | ✓ |
| 21 | LVBML(Low Voltage Battery Module) | Normal | ✓ | ✓ |
| 22 | PLCM(Power Rear Gate Control Module) | Normal | ✓ | ✓ |
| 23 | PMA(Park and Maneuver Assistance) | Normal | ✗ | ✓ |
| 24 | RHRDA(Right Rear Drive Assist Module) | Normal | ✓ | ✓ |
| 25 | RDCM(Rear Door Control Module) | Normal | ✓ | ✓ |

2.4.1.1. Introduction to the display of ECU Replacement

2.4.1.1.1.Introduction to the Controller List

The controller list includes: ECU Name, Status, Reprogramming File, and Configuration File



Note

The list of controllers displayed in this table only shows all the controllers that the current vehicle supports for diagnosis

| Project | Description |
|----------|---|
| ECU Name | All the controller of the current vehicle support for diagnosis |
| Status | The status descriptions of the corresponding controllers include: invalid VIN, unable to read VIN, VIN mismatch, hardware number mismatch, unable to read hardware number, unable to communicate with the module, database connection failure, and normal |

| Project | Description |
|--------------------|--|
| Reprogramming File | Compare the "ECU Information" and "Database Information" of the controller-related reprogramming file, and the result is shown as ✓, ✗, ?, ... |
| Configuration File | Compare the "ECU Information" and "Database Information" of the controller-related configuration file, and the result is shown as ✓, ✗, ?, ... |

2.4.1.1.2. Introduction to the Controller Status

Compare the VIN and hardware number read from the controller with the VIN (i.e., the VIN for vehicle identification) and hardware number in the database, and display the comparison results in the "Status" column to indicate the status of the controller. The statuses include: VIN not match, hardware number not match, no communication, and normal

| Status | Description |
|---------------------------|---|
| Normal | The data information in the controller and the database is obtained normally, and the VIN and hardware number read from the controller are consistent with the VIN and hardware number in the database (including the situation of a brand-new controller that has not had the VIN written into it) |
| VIN Not Match | The VIN read from the controller is inconsistent with the VIN in the database. |
| Hardware Number Not Match | The hardware number read by the controller is inconsistent with the hardware number in the database |
| No Communication | The communication with the controller fails |



Caution

- When the controller is in an abnormal state, diagnostic operations cannot be performed
- The VIN and hardware number in the database need to be consistent with the VIN and hardware number in the controller before subsequent operations can be carried out.
- The new controller cannot be read because the VIN has not been written yet, and it will not be determined as being in an abnormal state due to this reason

2.4.1.1.3. Introduction to the matching status

Compare the "ECU Information" and "Database Information" of the controller-related reprogramming file and configuration file, and the result is shown as , , , .



Caution

If there is no reprogramming file or configuration file information in both the "ECU Information" and the "Database Information", the corresponding matching status will also be displayed as "...", and the corresponding functions will not support "Reprogramming" or "Configuration"

| Matching Status | Description |
|---|---|
|  | The "ECU Information" and "Database Information" of all corresponding reprogramming files or configuration files are consistent, and the data in the controller is already the latest. There is no need to perform the reprogramming or configuration functions, but this does not affect the subsequent operations on the controller |
|  | The data version corresponding to this function in the controller on the vehicle is inconsistent with that in the database, but it does not affect the subsequent operations on the controller |
|  | At least one of the data information of the data version corresponding to this function in the controller on the vehicle and that in the database is empty, so no comparison can be made. |
|  | There is no data information for at least one of the data versions corresponding to this function in the controller on the vehicle and in the database, so a comparison cannot be made. |

2.4.1.2. Operation Process of ECU Replacement

The ECU replacement function is used to perform the programming and coding operations that must be carried out after the controller is replaced, such as software flashing, configuration writing, parameter setting, etc.


This paragraph takes the BPEPS (Bluetooth Passive Entry and Passive Start System) as an example to introduce the operation steps of the ECU replacement function.




Caution

- Each function may include several operation processes. The result will be displayed upon the completion of each operation process. Once all the operation processes are completed, the execution result of the function will be shown.
- The replacement function in the example includes multiple operation processes (such as reprogramming, configuration, setting, etc.) during the replacement operation.

Operation steps of the ECU replacement function:
 Step 1: Select BPEPS in the "ECU Replacement" interface




Step 2: After selecting BPEPS, click the [Next] button in the lower right corner of the interface, and it will jump to the interface shown in the following figure. The comparison and difference between the current vehicle's BPEPS software version and the latest baseline BPEPS software version in the database will be listed




Step 3: Click the [Start] button on the interface to enter the ECU replacement details interface. After performing operations on the vehicle according to the instructions in the pop-up window, click the [Next] button to start the reprogramming process during the replacement. The ADS will automatically execute the reprogramming process required for the ECU replacement.

"Reprogramming Operation 1/3" in the step: It indicates that the BPEPS replacement function has three operation processes, and currently the first operation process is being executed - the reprogramming operation.





Step 4: Once the flashing is successful, click [OK] button to proceed to the next process




The screenshot displays the ADS Online Mode interface during a BPEPS replacement procedure. The main window is titled 'BPEPS Replacement Step' and shows 'BPEPS Reprogramming 1/3'. The progress is divided into two sections: '1.Download' and '2.Execute'. Both sections show a progress bar that has reached 100%. A central dialog box with a blue information icon and the text 'Reprogramming Execution Successful' is overlaid on the interface, with an 'OK' button at the bottom. The left sidebar contains a 'Prompt Information' log with various diagnostic messages. The top right corner of the interface displays the VIN 'LSJWR4090RS104610' and the vehicle description '国家或地区代码/S12/品牌名称/车型系列/车型年/-'.

Step 5: After performing operations on the vehicle according to the instructions in the pop-up window shown in the following figure, click the [Next] button. In the ADS pop-up window, select "Continue" to start the configuration process during the replacement. The ADS will automatically execute the configuration process required for the ECU replacement.


"Configuration operation 2/3" in the step: It indicates that the BPEPS replacement function has three operation processes, and currently the second operation process is being executed - the configuration operation




Step 6: After completing the configuration operation, a prompt will indicate that the configuration operation has been successfully executed. Click the [OK] button to proceed with the next setting operation




Step 7: A prompt for the setting operation will be shown. Click the [Next] button "Setting operation 3/3" in the step: It indicates that the BPEPS replacement function has three operation processes, and currently the third operation process is being executed - the setting operation



Step 8: After completing the setting operation, a prompt will indicate that the setting operation has been successfully executed. Click the [OK] button to proceed to the next operation



Step 9: After the setting operation is completed, as shown in the following figure, the ADS client will display the execution result of the replacement function and list the execution results of each operation process. Clicking the [OK] button will end the function process and return to the main interface of ECU replacement




2.5. Routine

2.5.1. Introduction to the interface of Routine

Routine function is used for the quick maintenance process after the disassembly, assembly or replacement of sensors and actuators.

The Routine interface includes the execution of different special functions of parts for all the controllers of the current vehicle. The functions include, but are not limited to, adding/deleting NFC cards, controller self-learning, liquid filling and exhaust, and special calibration



The Routine list is classified according to the controllers and includes: Routine and Status.



Note

The Routine list only displays the self-learning functions supported by the currently vehicle


| Project | Description |
|---------|---|
| Routine | Self-learning items supported by the current vehicle controller |
| Status | The status description of the corresponding module, including no communication, normal, hardware number not match, etc. |

2.5.2. Routine - Operation Steps for Add NFC

This paragraph will introduce the operation steps by taking the addition of an NFC card as an example. The function Add NFC can add an NFC card to the vehicle

Operation steps of Add NFC


Step 1: Select the function Add NFC under the BCM in the Routine interface




The screenshot shows the 'Routine' interface in 'Online Mode'. The left sidebar contains various menu items, with 'Routine' selected. The main area displays a list of routine tasks. The task 'Add NFC' is highlighted in blue, indicating it is the current selection. The task is located under the 'BCM(Body Control Module)' category. The status of this task is 'Normal'.

| 序号 | Routine | Status |
|---|--|--------|
| BCM(Body Control Module) | | |
| 1 | BCM Power Mode Adjustment | Normal |
| 2 | TPMS Sensor ID Learning | Normal |
| 3 | Add NFC | Normal |
| 4 | Delete NFC | Normal |
| 5 | RENEW NFC IN module | Normal |
| 6 | RENEW NFC OUT module | Normal |
| BMS(Battery Management System) | | |
| 1 | BMS Parameter Reset | Normal |
| EPMCU(Electrical Parking Motor Control Unit) | | |
| 1 | Distance Self Learning | Normal |
| EPS(Electric Power Steering System) | | |
| 1 | EPS Calibration | Normal |
| FDR(Front Detection Radar) | | |
| 1 | Front Detection Radar Calibration | Normal |
| IBS(Brake Master Cylinder Booster Module) | | |
| 1 | Yaw Sensor Learning | Normal |
| 2 | ABS/SCS/IBS Refill/Bleeding | Normal |
| 3 | Parking Brake System Component Replacement | Normal |
| 4 | Parking Brake System Function Test | Normal |
| 5 | IBS System PSM/TMC Travel Sensor setup | Normal |
| ICB(Intelligent Computing Domain Controller Module) | | |
| 1 | Clear the OTA Task | Normal |


Step 2: Click the [Next] button to start the Add NFC operation. A pop-up window will prompt you with the precautions for the operation. Please be sure to follow the prompts. After confirming that the conditions in the prompts are met, click the [Next] button. "Add NFC operation 1/1" in the step: It indicates that the function of Add NFC has one operation process, and currently the first operation process is being executed - the Add NFC operation



Step 3: It will prompt the current number of valid NFC cards. If there are still NFC cards to be added, you need to click the [Next] button; if there are no new NFC cards to add, click the [Exit] button. Click the [Next] button.



Step 4: It will prompt you to place a new NFC card. Other cards should not be placed within 30cm of the placement area. After placing the new NFC card, click the [Next] button.




Step 5: Display the current result of Add NFC

The screenshot shows the ADS Online Mode interface during the 'BCM Add NFC 1/1' routine. The left sidebar displays a log of operations from 15:19:41 to 15:19:28. The main area shows the routine progress, with 'Download' completed at 100%. A modal dialog titled 'Add NFC' is displayed in the center, containing the message 'Current NFC has been added successfully!' and buttons for 'Exit' and 'Next'. The 'Next' button is highlighted with an orange arrow. The vehicle battery voltage is shown as 13.4 V.

Step 6: Click the [Next] button, and it will prompt the current number of valid NFC cards.

The screenshot shows the ADS Online Mode interface during the 'BCM Add NFC 1/1' routine. The log on the left sidebar has updated to 15:20:12. The modal dialog titled 'Add NFC' now displays the message 'The amount of valid NFCs is:1'. The 'Next' button remains highlighted with an orange arrow. The vehicle battery voltage is shown as 13.5 V.

Step 7: Click the [Next] button. It will prompt that the NFC card has been added successfully. Click the [OK] button to return to the express lane interface.




2.6. Baseline Management

Baseline Management includes Baseline Serial

2.6.1. Baseline Serial

Baseline Serial includes two functions: Baseline Reprogram and Baseline Config

The Baseline Serial interface includes contents such as the information prompt page, controller list, function list, etc.



| S/N | ECU Name | Function | Status | Reprogramming File | Configuration File | Select All |
|-----|--|---------------|--------|--------------------|--------------------|-------------------------------------|
| 1 | ICB(Intelligent Computing Domain Controller Mod... | Reprogramming | Normal | X | ✓ | <input checked="" type="checkbox"/> |
| 2 | IAM(Communication Module) | Reprogramming | Normal | X | ✓ | <input checked="" type="checkbox"/> |
| 3 | IPD(Intelligent Pilot Device) | Reprogramming | Normal | X | ✓ | <input checked="" type="checkbox"/> |
| 4 | IMU(Inertial Navigation Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 5 | EPS(Electric Power Steering System) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 6 | FLDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 7 | FRDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 8 | RLDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 9 | RRDCM(Right Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 10 | BPEPS(Bluetooth Passive Entry Passive Start) | Reprogramming | Normal | X | ✓ | <input checked="" type="checkbox"/> |
| 11 | BCM(Body Control Module) | Reprogramming | Normal | X | X | <input checked="" type="checkbox"/> |
| 12 | AMP(Audio System Power Amplifier) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 13 | EPMCU(Electrical Parking Motor Control Unit) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 14 | SCU(Shift Control Unit) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 15 | EOPC(Electrical Oil Pump Controller) | Reprogramming | Normal | X | ✓ | <input checked="" type="checkbox"/> |
| 16 | IBS(Brake Master Cylinder Booster Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 17 | FDR(Front Detection Radar) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 18 | LHRDA(Left Rear Drive Assist Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 19 | RHRDA(Right Rear Drive Assist Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 20 | PLCM(Power Rear Gate Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 21 | PMA(Park and Maneuver Assistance) | Reprogramming | Normal | X | ✓ | <input checked="" type="checkbox"/> |
| 22 | FLSM(Front Left Seat Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |



Caution

There is no need to select a controller on this page. You can directly select Baseline Reprogram or Baseline Config from the function list, and then click "Next".

2.6.1.1. Introduction to the Controller List

The Controller List includes two directories, namely Baseline Reprogram and Baseline Config. Each directory contains a sub-function list corresponding to the controller. The names of each column in the list are "ECU Name", "Function", "Status", "Reprogramming File", "Configuration File", and "Select All"



Caution

- Only the "Forced Refresh Configuration" in each column is editable, and it must be in the state where the background is white and the checkbox is not checked
- The list of controllers displayed in this table only shows all the controllers that the current vehicle supports for diagnosis

| Project | Description |
|--------------------|---|
| ECU Name | All controllers of the current vehicle that support the "Baseline Serial " function |
| Function | The function description of the corresponding controller, including Baseline Reprogram and Baseline Config |
| Status | The status descriptions of the corresponding controllers include: invalid VIN, unable to read VIN, VIN mismatch, hardware number mismatch, unable to read hardware number, unable to communicate with the module, database connection failure, and normal |
| Reprogramming File | Compare the "ECU Information" and "Database Information" of the controller-related reprogramming file, and the result is shown as  ,  ,  , ... |
| Configuration File | Compare the "ECU Information" and "Database Information" of the controller-related configuration file, and the result is shown as  ,  ,  , ... |
| Select All | According to the comparison results of the reprogramming file and the configuration file, it is displayed as  ,  ,  , and if it is actively checked, it will be displayed as  |

2.6.1.1.1.Introduction to the Controller Status

Compare the VIN and hardware number read from the controller with the VIN (i.e., the VIN for vehicle identification) and hardware number in the database, and display the comparison results in the "Status" column to indicate the status of the controller. The statuses include: VIN not match, hardware number not match, no communication, and normal

| Status | Description |
|---------------------------|---|
| Normal | The data information in the controller and the database is obtained normally, and the VIN and hardware number read from the controller are consistent with the VIN and hardware number in the database (including the situation of a brand-new controller that has not had the VIN written into it) |
| VIN Not Match | The VIN read from the controller is inconsistent with the VIN in the database. |
| Hardware Number Not Match | The hardware number read by the controller is inconsistent with the hardware number in the database |
| No Communication | The communication with the controller fails |



Caution

- When the controller is in an abnormal state, diagnostic operations cannot be performed
- The VIN and hardware number in the database need to be consistent with the VIN and hardware number in the controller before subsequent operations can be carried out.
- The new controller cannot be read because the VIN has not been written yet, and it will not be determined as being in an abnormal state due to this reason

2.6.1.1.2.Introduction to the matching status

Compare the "ECU Information" and "Database Information" of the controller-related reprogramming file and configuration file, and the result is shown as , , , 



Caution

If there is no reprogramming file or configuration file information in both the "ECU Information" and the "Database Information", the corresponding matching status will also be displayed as "...", and the corresponding functions will not support "Reprogramming " or "Configuration"

| Matching Status | Description |
|---|---|
|  | The "ECU Information" and "Database Information" of all corresponding reprogramming files or configuration files are consistent, and the data in the controller is already the latest. There is no need to perform the reprogramming or configuration functions, but this does not affect the subsequent operations on the controller |
|  | The data version corresponding to this function in the controller on the vehicle is inconsistent with that in the database, but it does not affect the subsequent operations on the controller |

| Matching Status | Description |
|-----------------|---|
| ? | At least one of the data information of the data version corresponding to this function in the controller on the vehicle and that in the database is empty, so no comparison can be made. |
| ... | There is no data information for at least one of the data versions corresponding to this function in the controller on the vehicle and in the database, so a comparison cannot be made. |

2.6.1.1.3. Introduction to Select All

When performing baseline reprogram and baseline config, by default, the vehicle controllers with the same part numbers as those of the server will be automatically skipped, and the functions will only be executed for the controllers with inconsistent part numbers. This column indicates whether to perform a forced reprogram or config. Users can choose whether to perform a forced reprogram or config for this controller

This column can only be checked when the status of the controller hardware number is normal and the part number is consistent with that of the server. In other cases, the ADS will automatically set whether it is selected or not, and it cannot be manually selected. The detailed description is as follows.

There are a total of four states for this column:

| Status | Description |
|-------------------------------------|--|
| <input type="checkbox"/> | The status of the corresponding controller is incorrect, and it cannot be selected for forced reprogram or config. Moreover, as long as there is any controller in this state in the list, it will cause the baseline reprogram or baseline config to be unable to proceed |
| <input type="checkbox"/> | The status of the corresponding controller is normal, and the part number is consistent with that of the server side. By default, baseline reprogram and baseline config are not required, but it can be manually selected to force baseline reprogram and baseline config |
| <input checked="" type="checkbox"/> | The state of the above button <input type="checkbox"/> after being manually selected represents that the forced reprogram or config has been manually chosen. Clicking it again will cancel the forced reprogram or config |
| <input checked="" type="checkbox"/> | It is mainly applied when the status of the controller is normal, but the part number is inconsistent with that of the server side. In this case, the ADS automatically sets to force baseline reprogram and baseline config, and it cannot be manually selected or cancelled. |

2.6.1.2. Introduction to Function List

Function List includes: Baseline Reprogram and Baseline Config

Perform software upgrades on controllers that are not of the latest baseline version

Baseline Reprogram:


Baseline Config: Perform configuration writing for controllers that are not of the latest baseline version.

2.6.1.3. Introduction to the Operation Steps of Baseline Serial

This paragraph will introduce the operation steps by taking the baseline reprogram as an example.

Operate steps of Baseline Reprogram

Step 1: Select Baseline Reprogram in the function list



| SN | ECU Name | Function | Status | Reprogramming File | Configuration File | Select All |
|---------------------------|--|---------------|--------|--------------------|--------------------|-------------------------------------|
| Baseline Reprogram | | | | | | |
| 1 | ICB(Intelligent Computing Domain Controller Mod... | Reprogramming | Normal | × | ✓ | <input checked="" type="checkbox"/> |
| 2 | IAM(Communication Module) | Reprogramming | Normal | × | ✓ | <input checked="" type="checkbox"/> |
| 3 | IPD(Intelligent Pilot Device) | Reprogramming | Normal | × | ✓ | <input checked="" type="checkbox"/> |
| 4 | IMU(Inertial Navigation Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 5 | EPS(Electric Power Steering System) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 6 | FLDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 7 | FRDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 8 | RLDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 9 | RRDCM(Right Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 10 | BPEPS(Bluetooth Passive Entry Passive Start) | Reprogramming | Normal | × | ✓ | <input checked="" type="checkbox"/> |
| 11 | BCM(Body Control Module) | Reprogramming | Normal | × | × | <input checked="" type="checkbox"/> |
| 12 | AMP(Audio System Power Amplifier) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 13 | EPMCU(Electrical Parking Motor Control Unit) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 14 | SCU(Shift Control Unit) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 15 | EOPC(Electrical Oil Pump Controller) | Reprogramming | Normal | × | ✓ | <input checked="" type="checkbox"/> |
| 16 | IBS(Brake Master Cylinder Booster Module) | Reprogramming | Normal | × | ✓ | <input type="checkbox"/> |
| 17 | FDR(Front Detection Radar) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 18 | LHRDA(Left Rear Drive Assist Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 19 | RHRDA(Right Rear Drive Assist Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 20 | PLCM(Power Rear Gate Control Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |
| 21 | PMA(Park and Maneuver Assistance) | Reprogramming | Normal | × | ✓ | <input checked="" type="checkbox"/> |
| 22 | FLSM(Front Left Seat Module) | Reprogramming | Normal | ✓ | ✓ | <input type="checkbox"/> |

Step 2: If the status of all controllers is normal, click the [Next] button to start the baseline reprogram

| Basic Information | | ECU Name | Function | Status | Reprogramming File | Configuration File |
|---------------------|--|---|---------------|--------|--------------------|--------------------|
| Basic Information | | ICB(Intelligent Computing Domain Controller Module) | Reprogramming | Normal | ✗ | ✓ |
| Vehicle Information | | IAM(Communication Module) | Reprogramming | Normal | ✗ | ✓ |
| ECU Information | | IPD(Intelligent Pilot Device) | Reprogramming | Normal | ✗ | ✓ |
| Basic Diagnosis | | IMU(Inertial Navigation Module) | Reprogramming | Normal | ✓ | ✓ |
| Vehicle Scan | | EPS(Electric Power Steering System) | Reprogramming | Normal | ✓ | ✓ |
| Data Playback | | FLDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ |
| ECU Function | | FRDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ |
| ECU Replacement | | RLDCM(Left Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ |
| Routine | | RRDCM(Right Rear Door Control Module) | Reprogramming | Normal | ✓ | ✓ |
| Routine | | BPPEPS(Bluetooth Passive Entry Passive Start) | Reprogramming | Normal | ✗ | ✓ |
| Baseline Management | | BCM(Body Control Module) | Reprogramming | Normal | ✗ | ✗ |
| Package Management | | AMP(Audio System Power Amplifier) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | EPMCU(Electrical Parking Motor Control Unit) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | SCU(Shift Control Unit) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | EOPC(Electrical Oil Pump Controller) | Reprogramming | Normal | ✗ | ✓ |
| Package Management | | IBS(Brake Master Cylinder Booster Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | FDR(Front Detection Radar) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | LHRDA(Left Rear Drive Assist Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | RHRDA(Right Rear Drive Assist Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | PLCM(Power Rear Gate Control Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | PMA(Park and Maneuver Assistance) | Reprogramming | Normal | ✗ | ✓ |
| Package Management | | FLSM(Front Left Seat Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | FRSM(Front Right Seat Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | ITMS(Heating, Ventilation and Air Conditioning) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | LVBM(Low Voltage Battery Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | SDM(Sensing Diagnostic Module) | Reprogramming | Normal | ✓ | ✓ |
| Package Management | | RMC(Battery Management Custom) | Reprogramming | Normal | ✓ | ✓ |

Step 3: The ADS automatically downloads the reprogram file and prompts the precautions for the baseline reprogram. Please be sure to operate according to the prompts. After confirming that the conditions in the prompts are met, click the [Next] button

ADS Online Mode
VIN: LSJWR4092RS083954
Vehicle Description: 国家或地区代码/S12/品牌名称/车型系列/车型年/
Authorization Days: 363

Baseline Serial

Vehicle Information

ECU Information

Basic Diagnosis

Vehicle Scan

Data Playback

ECU Function

ECU Replacement

Routine

Routine

Baseline Management

Package Management

Baseline Reprogram Step

VehicleBegin Begin 1/37

Total Functions: 1.Begin; 2.ICB Reprogramming; 3.IAM Reprogramming; 4.IPD Reprogramming; 5.IMU Reprogramming; 6.EPS Reprogramming; 7.FLDCM Reprogramming; 8.FRDCM Reprogramming; 9.RLDCM Reprogramming; 10.RRDCM Reprogramming; 11.BPPEPS Reprogramming; 12.BCM Reprogramming; 13.AMP Reprogramming; 14.SCU Reprogramming; 15.EOPC Reprogramming; 16.IBS Reprogramming; 17.FDR Reprogramming; 18.LHRDA Reprogramming; 19.RHRDA Reprogramming; 20.PLCM Reprogramming; 21.PMA Reprogramming; 22.FLSM Reprogramming; 23.FRSM Reprogramming; 24.ITMS Reprogramming; 25.LVBM Reprogramming; 26.Vehicle Power Off Reprogramming; 27.SDM Reprogramming; 28.BMS Reprogramming; 29.TC Reprogramming; 30.VMC Reprogramming; 31.VMC Configuration; 32.Vehicle Power Off Reprogramming; 33.CCU Reprogramming; 34.RWS Reprogramming; 35.IBS Configuration; 36.End; 37.Write TargetBaselineValue;


Begin

The Vehicle and Computer Remain Charged
 Computer Should Be Set to Non-sleep
 P is Selected
 Ensure that high power on the whole vehicle and the instrument "READY" is not lit
 Please open SIPS with administrator privileges.
 Network cable and other equipment are required for MPU upgrade

✗ Exit ➤ Next

Step 4: Start to automatically execute all the reprogram and config functions in the sub-function list of the baseline reprogram. During this process, if a pop-up window appears, please be sure to operate according to the prompts or click the [Next] button.


Step 5: After all the functions have been executed, the execution results of all functions will be displayed. Please ensure that the software prompts that the baseline reprogram function is successful.



2.7. Package Management

2.7.1. Offline Package

When the offline package is officially released later, the specific usage method of this function will be attached



2.8. Auxiliary Functions

The auxiliary function icons of the ADS client are displayed in the upper right corner of the page, including: Home Page, Open the File Synchronization Tool, Open VCI Manager, Help Documentation, Setting, Export Logs, and Connect Status. This section introduces the operation steps of the auxiliary functions.



| Icon | Description |
|---|---|
|  | Return to home page |
|  | open the file synchronization tool |
|  | open the VCI Manager |
|  | Open the relevant help documents of the ADS |
|  | Modify the language settings. Currently, it supports switching between two languages, Chinese and English |
|  | Export the log file of the ADS client |
|  | Switch between online mode and offline mode |
|  | This icon shows the connection status of the VDI. |

2.8.1. Home Page

The button  in the upper right corner of the ADS client is the "Home Page" function: When the ADS client is in use, clicking this button will take you back to the vehicle identification interface.




Caution

- This function cannot be used during the communication process between the ADS client and the vehicle or the server side
- After returning to the home page, the information of the last vehicle identification will be cleared

2.8.2. Open the File Synchronization Tool

The button  in the upper right corner of the ADS client is the function of "Opening the File Synchronization Tool": Download large-sized data to the local device



Caution


- When the ADS is launched for the first time after installation, the file synchronization tool will prompt you to set the storage path. Please set it reasonably according to the actual hard disk capacity of the diagnostic computer. After selecting the storage path, the tool will create a folder under this path, and the file synchronization tool window will pop up
- To ensure the stable operation of the diagnostic computer system, do not set the storage path for large-sized files in the partition where the Windows system is installed.
- If there are already large-sized files on the local computer, you can set the storage path according to their existing location, that is, the parent level of the TCE_AVAILABLE folder
- If you change the storage path for large-sized files, you need to modify the storage path first and then migrate the historical files

After clicking , the file synchronization tool will pop up, click the [Start Download] button



Caution

- Please turn off the hibernation/sleep function of the diagnostic computer to ensure that the diagnostic computer remains in operation throughout the download process
- In order to enhance the customer experience and reduce the maintenance waiting time, please perform a full synchronization of large-sized data at least once a day



| OSS Directory | File Name | File Size | Ecu | Status | Operate |
|---------------|----------------|-----------|-----|----------------|---------|
| TCE_AVAILABLE | 10773313-14.51 | 125.54 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11003066-08.51 | 1.91 GB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11015301-07.51 | 183.16 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11015305-07.52 | 127.00 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11240234-06.51 | 122.93 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11306966-01.51 | 1.71 GB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11335399.51 | 125.43 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11366091.51 | 2.46 GB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11368497.51 | 175.21 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11368498.52 | 124.32 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11369769.51 | 1.57 GB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11369969.51 | 125.15 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11370651.51 | 194.43 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11371429.51 | 3.83 GB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11378112.51 | 2.46 GB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11380032.51 | 125.25 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11387307.51 | 187.53 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11387308.52 | 124.32 MB | | Not Downloaded | ✓ |
| TCE_AVAILABLE | 11391432.51 | 194.37 MB | | Not Downloaded | ✓ |

2.8.3. Open VCI Manager

This function is only applicable in the scenario where the diagnostic computer and the vehicle are connected via the VDI (Vehicle Communication Interface)

When the vehicle is connected using an OBD network cable, this function cannot be used

2.8.4. Help Documentation


The button  in the upper right corner of the ADS client can be used to open the help documentation of ADS.

2.8.5. Setting

The button  in the upper right corner of the ADS client can be used to set the display language of the ADS client. Currently, it supports switching between Chinese and English.

The operation steps for language setting

Step 1: Click the button , and a pop-up window will open the language settings interface.



Step 2: Select the language you need to set, click "OK", and the ADS client will automatically restart

2.8.6. Export Logs

The button  in the upper right corner of the ADS client is the "Export Log" function: to export the log file of the ADS client


The operation steps for exporting the log

Step 1: Click the button , and a pop-up window will open the interface for exporting logs

Step 2: Enter at least one query condition, either the VIN or the time, and press Enter to list the log files that meet the conditions. The displayed log file information includes the VIN, generation time, and file size

Step 3: The log files are named after the VIN and the generation time. Please confirm and select the file you need to export according to the VIN and the generation time. Click the [Export] button, select the export path, and save the file after clicking "OK".

Step 4: Click on the corresponding element (such as a close button or icon) within the "Export Logs" interface to close the log export window



| Select | SN | VIN | Creation Time | File Size |
|--------|----|-----|---------------|-----------|
|--------|----|-----|---------------|-----------|

2.8.7. Online/Offline Mode Switching

This function will be released in later version

2.8.8. Connect Status


The button  in the upper right corner of the ADS client shows the connect status of VDI, you can ignore it when connecting the vehicle with the OBD network cable

Chapter III Other Matters


3.1. Environmental Settings

3.1.1. Steps for Firewall Settings


Step 1: Open Control Panel, click [System and security]




Step 2: Click [Windows Defender Firewall]



Step 3: Click [Advanced settings]




Step 4: Confirm whether the firewall has been completely turned off. If it has not been turned off, click on "Windows Defender Firewall Properties"



- Step 5: Select the "Domain Profile", set the firewall state to "Off", click the [Apply] button
- Step 6: Select the "Private Profile", set the firewall state to "Off", click the [Apply] button
- Step 7: Select the "Public Profile", set the firewall state to "Off", click the [Apply] button

Step 8: Click the [OK] button.




Step 9: Confirm the firewall again. It must be completely turned off in all aspects


3.1.2. MSMQ (Microsoft Message Queue) Settings

Step 1: Select the Windows Features path on the diagnostic computer: Start → Control Panel → Programs → Programs and Features.

Click [Turn Windows features on or off]




Step 2: Locate "Microsoft Message Queue (MSMQ) Server" in the list. Confirm whether it is checked. If it is not checked, please check the box and then click [OK].



3.1.3. Route Settings

Step 1: Enter "Command Prompt" in the search bar

Step 2: Right-click and select "Run as administrator" to open the Command Prompt



Caution

- Be sure to run the Command Prompt as an administrator
- If it is prompted that the requested operation requires elevation, it indicates that the user does not have Windows administrator privileges or has not run it as an administrator

```
Microsoft Windows [Version 10.0.22631.4890]
(c) Microsoft Corporation. All rights reserved.

C:\Users\oxfoh7>route add 172.31.7.0 mask 255.255.255.0 172.31.6.2 -p
The requested operation requires elevation.

C:\Users\oxfoh7>
```

Step 3: Enter "route print" and press the Enter key

```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.22631.4890]
(c) Microsoft Corporation. All rights reserved.
C:\Windows\System32>route print
```

Step 4: Check whether there are the following two permanent routes in the IPv4 routing table.

| Network Address | Netmask | Gateway Address |
|-----------------|---------------|-----------------|
| 172.31.7.0 | 255.255.255.0 | 172.31.6.2 |
| 172.31.3.0 | 255.255.255.0 | 172.31.6.2 |

- If there are, the Route has been set
- If not, proceed to Step 5

```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.22631.4890]
(c) Microsoft Corporation. All rights reserved.
C:\Windows\System32>route print
=====
Interface List
17...30 24 a9 8b d7 cd .....Realtek PCIe GbE Family Controller
15...fc b3 bc 41 83 0a .....Microsoft Wi-Fi Direct Virtual Adapter #3
19...fe b3 bc 41 83 09 .....Microsoft Wi-Fi Direct Virtual Adapter #4
 8...00 09 0f fe 00 01 .....Fortinet Virtual Ethernet Adapter (NDIS 6.30)
23...fc b3 bc 41 83 09 .....Intel(R) Wi-Fi 6 AX201 160MHz
21...fc b3 bc 41 83 0d .....Bluetooth Device (Personal Area Network) #2
1.....Software Loopback Interface 1
=====
IPv4 Route Table
=====
Active Routes:
Network Destination        Netmask          Gateway          Interface        Metric
0.0.0.0                    0.0.0.0          10.182.88.1     10.182.88.65     35
10.182.88.0                255.255.254.0    On-link         10.182.88.65     291
10.182.88.65               255.255.255.255 On-link         10.182.88.65     291
10.182.89.255              255.255.255.255 On-link         10.182.88.65     291
127.0.0.0                  255.0.0.0        On-link         127.0.0.1        331
127.0.0.1                  255.255.255.255 On-link         127.0.0.1        331
127.255.255.255           255.255.255.255 On-link         127.0.0.1        331
224.0.0.0                  240.0.0.0        On-link         127.0.0.1        331
224.0.0.0                  240.0.0.0        On-link         10.182.88.65     291
255.255.255.255           255.255.255.255 On-link         10.182.88.65     291
=====
Persistent Routes:
Network Address            Netmask          Gateway Address  Metric
172.31.0.0                 255.255.0.0     172.31.6.80     1
255.255.255.255           255.255.255.255 172.31.6.80     1
172.31.7.0                 255.255.255.0   172.31.6.2      1
172.31.3.0                 255.255.255.0   172.31.6.2      1
=====
IPv6 Route Table
```


Step 5: Enter the following two lines of commands respectively and press the Enter key:

```
route add 172.31.7.0 mask 255.255.255.0 172.31.6.2 -p
```

```
route add 172.31.3.0 mask 255.255.255.0 172.31.6.2 -p
```

If the operation is completed, re-execute Steps 3-4

If it fails, please contact the TAC



```
Administrator: Command Prompt
Microsoft Windows [Version 10.0.22631.4890]
(c) Microsoft Corporation. All rights reserved.


C:\Windows\System32>route add 172.31.7.0 mask 255.255.255.0 172.31.6.2 -p
The route addition failed: The object already exists.

C:\Windows\System32>route add 172.31.3.0 mask 255.255.255.0 172.31.6.2 -p
The route addition failed: The object already exists.


C:\Windows\System32>
```

3.1.4. Computer's IP Address Setting


Step 1: Navigate through the Windows features path: Control Panel → Network and Internet → Network and Sharing Center. Check the currently active Ethernet connection, and click the [Change adapter settings] button




Step 2: Locate the currently active Ethernet connection, right-click on it and select "Properties"



Step 3: Select "Internet Protocol Version 4 (TCP/IPv4)" and click the [Properties] button



Step 4: Select "Use the following IP address". Enter the IP address: 172.31.6.80. After clicking in the Subnet Mask field, the system will automatically fill it in and there is no need to modify it. Then click the [OK] button




3.2. Frequently Asked Questions

3.2.1. The vehicle cannot be identified and prompts "DoIP network connection failed"

Cause analysis: ADS has high requirements for the diagnostic computer environment. If the parameter settings are incorrect, the vehicle cannot be recognized

Recommended action: Check the environment and re-identify it, see *Chapter III Other Matters - > 3.1 Environmental Settings*



3.3. Any question, please contact the TAC of the corresponding region



Note

Refer to *TB-ALL-GE-2024102502-Announcement on the Adjustment of the On-site TAC Region*