

Code Project	Vehicles	VCI Alliance	VCI ADT	Tool	Config.	Reprog.	Gateway	EURO5 J2534	EURO5 DOIP
DACIA	1304 / 1305 / 1310	-	-	ASDE	-	-	-	NO	
DACIA	D-Cab	-	-	ASDE	-	-	-	NO	
DACIA	Double Cab	-	-	ASDE	-	-	-	NO	
DACIA	SUPERNOVA / SOLENZA	-	-	ASDE	-	-	-	NO	
SM3	SCALA / SM3-CF	X	X	BORNEO2 RSM				NO	
SM3	SM3	X	X	BORNEO2 RSM				NO	
SM5	SAFRANE2.0 / SM5-DF (DLC1/DLC2 connector)	X		BORNEO2 RSM				NO	
SM5	SM5 – EX (DLC1/DLC2 connector)	X		BORNEO2 RSM				NO	
SM5	SM5	X	X	BORNEO2 RSM				NO	
SM7	SAFRANE 2.3 / SM7-LF (DLC1/DLC2 connector)	X		BORNEO2 RSM				NO	
SM7	SM7	X	X	BORNEO2 RSM				NO	
X06	TWINGO, TWINGO ph2	X		ASDE				NO	
X07	TWINGO III	X	X	BORNEO3	X	X		YES	
X07	TWINGO III Ph2, TWINGO Z.E.	X	X	BORNEO3	X	X		YES	
X09	TWIZY	X	X	BORNEO2		X		YES	
X10	ZOE	X	X	BORNEO3	X	X		YES	
X10	NOUVELLE ZOE Ph2	X	X	BORNEO3	X	X	X	YES	
X20	TRAFIC I	X		ASDE				NO	
X24	MASTER PROP.	X		ASDE				NO	
X24	MAST.PRO.ph3	X	X	BORNEO2				NO	
X25 (X64)	MEGANE	X		ASDE				NO	
X29	R25	X		ASDE				NO	
X33	WIND	X	X	BORNEO2	X	X		YES	
X35	THALIA/SYMB.2	X	X	BORNEO2		X		YES	
X37	R11	X		ASDE				NO	
X38	NEW SM3 / FLUENCE / MEGANE	X	X	BORNEO3	X	X		YES	
X40	EXPRESS	X		ASDE				NO	
X40	SUPER 5	X		ASDE				NO	
X42	R9	X		ASDE				NO	
X43	LATITUDE / SM5	X	X	BORNEO3	X	X		YES	
X44	TWINGO II	X	X	BORNEO2		X		YES	
X45	KOLEOS / QM5	X	X	BORNEO2		X		YES	
X47	SM7 - L47	X	X	BORNEO3				NO	
X48	R21 / NEVADA	X		ASDE				NO	
X50	ALPINE	X		ASDE				NO	
X52	LOGAN II / SANDERO II	X	X	BORNEO3	X	X		YES	
X53	R19	X		ASDE				NO	
X54	SAFRANE	X		ASDE				NO	
X55	ALASKAN	X	X	BORNEO2				NO	
X56	LAGUNA, LAGUNA ph2	X		ASDE				NO	
X57	CLIO I	X		ASDE				NO	
X61	KANGOO II	X	X	BORNEO2		X		YES	
X61	KANGOO ZE /StopStart /ph2	X	X	BORNEO3	X	X		YES	
X62	MASTER III	X	X	BORNEO3	X	X		YES	
X63	ESPACE II	X		ASDE				NO	
X64	MEGANE / SCEN. (MEGANE I, SCENIC I, CLASSIC I)	X		ASDE				NO	

Code Project	Vehicles	VCI Alliance	VCI ADT	Tool	Config.	Reprog.	Gateway	EURO5 J2534	EURO5 DOIP
X65	CLIO II, CLIO IIp2/3/4, CLIO V6 / CLIO V6 ph2, THALIA/SYMBOL	X		ASDE				NO	
X65 Ph6	CLIO II ph6	X	X	BORNEO2		X		YES	
X66	ESPACE III	X		ASDE				NO	
X66	AVANTIME	X		ASDE				NO	
X67	DOKKER / KANGOO	X	X	BORNEO3	X	X		YES	
X70	MAST.PRO.ph2	X		ASDE				NO	
X70	MASTER	X		ASDE				NO	
X70	MASTER Ph3	X	X	BORNEO2				NO	
X73	VEL SATIS, VELSATIS ph2	X	X	BORNEO2				NO	
X74	LAGUNA II, LAGUNAII ph2	X	X	BORNEO2				NO	
X76	KANGOO	X		ASDE				NO	
X76	KANGOO MUX	X		ASDE				NO	
X76	KANGOO VLL	X	X	BORNEO2				NO	
X77	MODUS	X	X	BORNEO2		X		YES	
X79	DUSTER	X	X	BORNEO2		X		YES	
X79	DUSTER Ph2	X	X	BORNEO3	X	X		YES	
X81	ESPACE IV	X	X	BORNEO2		X		YES	
X81	ESPACE IV Ph2/3/4	X	X	BORNEO2		X		YES	
X82	TRAFIC III Ph2		X	ADT	X	X	X	YES	
X82	TRAFIC III Phase 1, 1'	X	X	BORNEO3	X	X		YES	
X83	TRAFIC II	X		ASDE				NO	
X83	TRAFIC II Ph2/3	X	X	BORNEO2		X		YES	
X84	MEGANE II, SCENIC II	X	X	BORNEO2				NO	
X85	CLIO III	X	X	BORNEO2		X		YES	
X87	CAPTUR / QM3 / KABIN	X	X	BORNEO3	X	X		YES	
X90	LOGAN, SANDERO	X	X	BORNEO2		X		YES	
X91	LAGUNA III	X	X	BORNEO3	X	X		YES	
X92	LODGY	X	X	BORNEO3	X	X		YES	
X94	SPIDER	X		ASDE				NO	
X95	MEGANE III / SCENIC III	X	X	BORNEO3	X	X		YES	
X98	CLIO IV	X	X	BORNEO3	X	X		YES	
XBA	KWID	X	X	BORNEO3				NO	
XBB	KWID BR	X	X	BORNEO3				NO	
XBC	TRIBER	X	X	BORNEO3				NO	
XBG	CITY K-ZE / SPRING	X	X	BORNEO3	X	X		YES	
XCB	MEGANE eTECH ELECTRIC		X	ADT	X	X	X	NO	X
XEF	ALPINE A110	X	X	BORNEO3				NO	
XFA	SCENIC IV	X	X	BORNEO3	X	X		YES	
XFA	SCENIC IV PH2	X	X	BORNEO3	X	X	X	YES	
XFB	MEGANE IV, MEGANE IV SEDAN			BORNEO3	X	X		YES	
XFB	MEGANE IV, MEGANE IV SEDAN Ph2			BORNEO3	X	X	X	YES	
XFC	ESPACE V	X	X	BORNEO3	X	X		YES	
XFC	ESPACE V Ph2			BORNEO3	X	X	X	YES	
XFD	TALISMAN / SM6	X	X	BORNEO3	X	X		YES	
XFD	SM6 Ph2			BORNEO3			X	YES	
XFD	TALISMAN			BORNEO3	X	X	X	YES	
XFE	KADJAR	X	X	BORNEO3	X	X		YES	
XFF	MEGANE IV SEDAN, MEGANE IV SEDAN Ph2	X	X	BORNEO3	X	X	X	YES	

Code Project	Vehicles	VCI Alliance	VCI ADT	Tool	Config.	Reprog.	Gateway	EURO5 J2534	EURO5 DOIP
XFK	KANGOO III		X	ADT	X	X	X	YES	
XHA	CAPTUR / KAPTUR BR/IN/RU	X	X	BORNEO3				NO	
XHN	AUSTRAL		X	ADT	X	X	X	NO	X
XJA	CLIO V	X	X	BORNEO3	X	X	X	YES	
XJB	CAPTUR II	X	X	BORNEO3	X	X		YES	
XJB	CAPTUR II Ph2	X	X	BORNEO3	X	X	X	YES	
XJC	ARKANA (Russie)	X	X	BORNEO3	X	X	X	NO	
XJD	DUSTER ph3	X	X	BORNEO3	X	X		YES	
XJE	CAPTUR II CN	X	X	BORNEO3			X	NO	
XJF	SANDERO III	X	X	BORNEO3	X	X	X	YES	
XJH	ARKANA CN	X	X	BORNEO3	X	X	X	NO	
XJI	LOGAN III / SANDERO III	X	X	BORNEO3	X	X	X	YES	
XJK	EXPRESS II	X	X	BORNEO3	X	X		YES	
XJL	XM3 / NEW ARKANA	X	X	BORNEO3			X	YES	
XZG	KOLEOS II / QM6	X	X	BORNEO3	X	X		YES	
XZH	KADJAR CN	X	X	BORNEO3				NO	
XZJ	KOLEOS II CN / QM6 CN	X	X	BORNEO3				NO	